

OTC TENT SETUP INSTRUCTIONS



1. Check installation site for buried lines and overhead power lines and any other obstructions.
2. Lay tent top on a clean installation area and square the corners flat on the ground with colored side facing up.
3. Step straight out from grommet (rope attach point) 4 steps and drive stake about half way down.
4. Tie rope to stake at about 9' from tent, the rope will be trained where it was tied previously.
5. Lift side of tent and install 7' side pole through grommet and rope. Do this all the way around the perimeter, (tent should look like it is upside down).
6. Assemble sectional center pole and walk under tent while lifting top by hand and insert center pole peg into middle grommet.
7. Lift center pole and tie the jump rope to the center pole to secure it from falling from tent as you finish installation.
8. Secure ropes and then go around and drive stakes to full depth.

